NEXUS TABLETS- Pairing tablets to Catch Computer

Pairing tablets to Catch computer using BlueSoleil application



- 1. Turn Data Entry PC on (and ensure that Bluetooth dongle is plugged into computer).
- 2. Check tablet to see if Bluetooth is on. If you have completed tablet setup- Bluetooth will be on.
 - a. Swipe down from top of tablet screen.
 - 1. If Bluetooth is not turned on
 - Turn Bluetooth ON by tapping

 * (Nexus tablet).
 - b. A menu will appear at the top menu (dark grey bar)
 - c. Tap Bluetooth button *) so it is highlighted in white.
 - d. Tap small down arrow button (Bluetooth ') found directly below Bluetooth symbol.
 - e. Select the NOAADATA-PC option that corresponds with your data entry
 - f. Tap more settings. The NOAADATA-PC should appear under the paired devices header.
- 3. Open the BlueSoleil application on the PC.
 - a. under the view menu, select Refresh Devices (or press F5)
 - b. The tablet you are trying to connect should appear in the BlueSoleil solar system.
 - c. Right click on the tablet icon -> select Pair Device
 - d. Type in ANY four digit numerical passkey
- 4. A pairing request should then appear on your tablet. Open pairing request, and type in same passkey that you just entered into the computer and click OK. You have 30 seconds to type in passwords on both devices. Now the devices are paired and connected!

5. IF: an IP address such as 30:3T:4P:6C appears under BlueSoleil icon ->double-click the number and the tablet_ID names should appear (e.g., BA01, YA01, RA01, etc.)

TROUBLESHOOTING:

- 1. If tablet is not appearing in the BlueSoleil solar system, you can also initiate pairing through the tablet's Bluetooth settings. Enter the tablet's settings menu) found in the top pull down menu, then under Wireless & Networks select Bluetooth. Click on the NOAADATA-PC, type in four-digit passkey of your choice. Window should then pop up on catch computer, enter same four-digit passkey into dialogue box.
- 2. If tablet is already paired and some amount of time has passed, the tablet will not be "searchable" and thus won't be visible in the BlueSoleil solar system, but the tablet and computer will still be paired. If experiencing connection problems, turn off tablet Bluetooth and try re-pairing.
- 3. SHORTCUT: To make Tablet_ID's reappear in the BlueSoleil solar system after rebooting the Catch computer, click on Tools>Add Device from History and choose the Tablet_ID's that you want to add from the list